



**SWITCHES, SOCKETS
& WIRING ACCESSORIES**

SIMPLICITY[™]

SIMPLICITY™

SWITCHES & SOCKETS

Simplicity is the ideal choice for any contemporary home. Sleek, modern, streamlined design with a sophisticated look to enhance any room. With four different colour varieties available, you're sure to find a shade to match your room, whatever your style.

The covers are interchangeable, so you can change the look whenever you like. You don't have to worry about your switches not matching if you redecorate, and you won't need any complicated re-wiring to change them.


The switches fit easily into a standard 25mm back box. All of our switches are UK-designed, and for further peace of mind, there is a brilliant 10 year guarantee.

At Retrotouch we think 'the small details make the biggest difference.'

AVAILABLE IN 4 FINISHES:



MID GREY



WHITE



BRONZE



CHARCOAL

WWW.SMARTHOMEGCC.COM



SIMPLICITY™ LIGHT SWITCHES

Our fantastic mechanical rocker light switches are now available in high quality & durable plastic finish.

With a sleek, modern design, these switches are the ideal choice for a contemporary home. They come with large, easy press buttons and screw-less fronts, creating a streamlined and sophisticated look in any room. At Retrotouch we think the small details make the biggest difference.

With four different colour variants available, you're sure to find a shade to match your room, whatever your style. The covers are interchangeable, so you can change the look whenever you like. You won't have to worry about your switches not matching your wall paint if you redecorate, and you won't need any complicated re-wiring to change them.

The switches fit easily into a standard 25mm back box. All of our switches are UK-designed, and for further peace of mind, there's a brilliant 10 year guarantee.



ONE GANG



ONE WAY & TWO WAY

White: 07000 Mid Grey: 07002
Charcoal: 07003 Bronze: 07004

INTERMEDIATE

White: 07140 Mid Grey: 07142
Charcoal: 07143 Bronze: 07144

TWO GANG



ONE WAY & TWO WAY

White: 07020 Mid Grey: 07022
Charcoal: 07023 Bronze: 07024

THREE GANG



ONE WAY & TWO WAY

White: 07040 Mid Grey: 07042
Charcoal: 07043 Bronze: 07044

FOUR GANG



ONE WAY & TWO WAY

White: 07060 Mid Grey: 07062
Charcoal: 07063 Bronze: 07064

SIMPLICITY™ PLUG SOCKETS

Our outstanding Simplicity 13A double switched sockets are now available in high quality and durable plastic finish. With a sleek, modern design, these sockets are the ideal choice for a contemporary home. They come with screw-less fronts, creating a streamlined and sophisticated look in any room.

At Retrotouch we think the small details make the biggest difference.

With four different colour varieties available, you're sure to find a shade to match your room, whatever your style. The covers are interchangeable, so you can change the look whenever you like. You won't have to worry about your switches not matching if you redecorate, and you won't need any complicated re-wiring to change them.

The sockets fit easily into a standard 25mm back box. All of our switches are UK-designed, and for further peace of mind, there's a brilliant 10 year guarantee.



13A SINGLE SWITCHED SOCKET



WHITE
07320



MID GREY 07322 CHARCOAL 07323 BRONZE 07324

13A DOUBLE SWITCHED SOCKET



MID GREY
07442



WHITE 07440 CHARCOAL 07443 BRONZE 07444

13A SINGLE SOCKET WITH USB



CHARCOAL
07363



MID GREY 07362 WHITE 07360 BRONZE 07364

13A PLUG SOCKET WITH DP COOKER SWITCH



BRONZE
07544



WHITE 07540 CHARCOAL 07443 MID GREY 07442

SIMPLICITY™
ROTARY DIMMERS & PULSE SWITCHES



1 GANG DIMMER

□ 07200 ■ 07202
 ■ 07203 ■ 07204



2 GANG DIMMER

□ 07220 ■ 07222
 ■ 07223 ■ 07224



1 GANG PULSE RETRACTIVE

□ 07080 ■ 07082
 ■ 07083 ■ 07084

SIMPLICITY™
WIRING ACCESSORIES



FAN ISOLATOR

□ 08010 ■ 08012
 ■ 08013 ■ 08014



25A FLEX OUTLET

□ 07780 ■ 07782
 ■ 07783 ■ 07784



TV / FM SOCKET

□ 07600 ■ 07602
 ■ 07603 ■ 07604

WIRING ACCESSORIES



BT MASTER SOCKET

□ 07740 ■ 07742
 ■ 07743 ■ 07744



BT SLAVE SOCKET

□ 07760 ■ 07762
 ■ 07763 ■ 07764



DOUBLE RJ45 SOCKET

□ 07680 ■ 07682
 ■ 07683 ■ 07684



45A SWITCH

□ 07300 ■ 07302
 ■ 07303 ■ 07304



20A SWITCH

□ 07260 ■ 07262
 ■ 07263 ■ 07264



13A FUSED SPUR

□ 07820 ■ 07822
 ■ 07823 ■ 07824



TV AND SATELLITE

□ 07620 ■
 ■ 07623 ■ 07624



SATELLITE SOCKET

□ 07640 ■ 07642
 ■ 07643 ■ 07644



SINGLE TV SOCKET

□ 07560 ■ 07562
 ■ 07563 ■ 07564



13A UNSWITCHED FUSED SPUR

□ 07800 ■ 07802
 ■ 07803 ■ 07804



2 & 4 GANG EURO MODULE PLATE

□ 07850	■ 07852	□ 07850	■ 07852
■ 07853	N/A	■ 07854	07864



SHAVER SOCKET

□ 08030 ■ 08032
 ■ 08033 ■ 08034